



PlayStation®Camera

Instruction Manual / 使用説明書 / 使用说明书 / 사용설명서
CUH-ZEY2 4-594-815-11(1)

EN

Precautions

Before using this product, carefully read this manual and any manuals for compatible hardware. Retain instructions for future reference.

Safety


- Keep this product out of the reach of small children. Small children may swallow small parts or may wrap the cables around themselves, which may inflict injury or cause an accident or a malfunction.
- Do not touch the product with wet hands.
- Never disassemble or modify the product.
- Check that there is no dust or foreign object on the connectors when connecting cables.
- Do not allow liquid or small particles to get into the product.
- Do not expose the product to dust, smoke or steam.
- Do not expose the product to high temperatures, high humidity or direct sunlight.

Use and handling


- Do not let any other metal items come in contact with the connectors.
- Do not place any objects on top of the product. Do not stand on the product.
- Do not throw or drop the product, or otherwise expose it to strong physical impact.
- Do not place the product on surfaces that are unstable, tilted or subject to vibration.
- Do not allow the product to come into contact with liquids.
- Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored.
 - Wipe with a soft, dry cloth.
 - Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
 - Do not use solvents or other chemicals. Do not wipe with a chemically treated cleaning cloth.

Attaching the stand

1 Insert the camera into the stand, as shown in the figure.



2 Push the base of the cable into the stand, as shown in the figure.




Connecting and installing

Connect the camera to the PS4™ system's AUX port, and then place the camera on top (center) or in front (center) of the TV.


Placing the camera on top of a TV

To prevent the camera from falling, secure the stand on top of the TV by bending it into position.




Placing the camera in front of a TV

You can also use the stand by bending it into position.



Hints

- If the camera is not recognized by the PS4™ system, disconnect the camera cable, and then reconnect it. If the camera is still not recognized, turn off the PS4™ system, and then turn it on again.
- If the dual lenses of the Camera become dirty, wipe them with a soft cloth.
- Adjust the angle by rotating the camera. You can also adjust the angle by bending the stand. Note that if you rotate the camera too much, it may detach from the stand.



Specifications

Input Power Rating	DC 3.5V, 500 mA
External dimensions	Approx. 159 × 28 × 28 mm (width × height × depth) (excluding stand)
Mass	Approx. 152 g (excluding stand)
Video pixels	(maximum) 1280 × 800 pixels × 2
Camera	Stereo camera
Camera range	30 cm ~ ∞/85 °
Microphones	4-channel microphone array
Cable length	Approx. 2 m
Operating temperature	5 °C - 35 °C

Design and specifications are subject to change without notice.

CT

使用前須知事項

使用本產品前，請先詳細閱讀本使用說明書和對應裝置的所有說明書，並妥善保存，以備將來參考之用。

關於安全


- 請將本產品放在兒童拿不到的地方保管。兒童可能會吞下細小零件或用連接線纏繞自己，而造成身體損傷或導致意外發生、機器故障。
- 請勿用濕手觸摸本產品。
- 切勿分解、改造本產品。
- 連接時，請勿讓灰塵或異物堆積於端子四周。
- 請勿讓液體或小顆粒掉入本產品中。
- 請勿將本產品暴露在灰塵、煙霧或蒸氣中。
- 請勿將本產品放在高溫、濕氣極重或受日光直射的地方。

使用與保管


- 請勿讓金屬物品碰觸連接端子部位。
- 請勿在本產品上放置重物。請勿在本產品上站立。
- 請勿投擲或掉落本產品，或使其受到強烈的外力撞擊。
- 請勿將本產品放在傾斜、不平整或易受振動的地方。
- 請勿讓本產品被液體沾濕。
- 請遵循以下使用說明，以免產品外殼變形或變色。
 - 使用乾淨軟布輕柔擦拭。
 - 切勿在產品外殼上長時間放置任何橡膠或乙烯基材質。
 - 切勿使用溶劑或其他化學藥劑。切勿使用經化學處理的擦布擦拭。

安裝支架

1 如圖所示，將攝影機裝設進支架上。



2 如圖所示，將連接線的尾端推到底。




連接 / 設置

將攝影機連接至 PS4™ 主機的 AUX 連接埠，並將攝影機設置在電視機的上方（中央）或前方（中央）。


將攝影機設置在電視機的上方

為預防攝影機掉落，彎曲支架以固定在電視機上方的位置。




將攝影機設置在電視機的前方

支架亦可彎曲使用。



提示

- 若PS4™主機無法辨識攝影機，請拔除並重新連接攝影機的連接線。若主機仍無法辨識攝影機，請關閉PS4™主機的電源後再重新啟動。
- 弄騰攝影機的雙鏡頭時，請以柔軟的布擦拭。
- 可調整攝影機的角度。亦可彎曲支架進行調整。請注意不要過度旋轉攝影機，否則可能會導致支架與攝影機分離。



規格

額定電壓，額定輸入電流	DC 3.5V, 500 mA
外觀尺寸	約 159 × 28 × 28 mm(寬 × 高 × 深) (不含支架)
重量	約 152 g (不含支架)
影片像素	(最大) 1280 × 800 像素 × 2
攝影機	立體攝影機
攝影範圍	30 cm ~ ∞ / 85 °
麥克風	四聲道陣列式麥克風
連接線長度	約 2 m
操作溫度	5 °C – 35 °C

本公司保留在沒有事先通知情況下，變更設計或規格之權利。

CS

使用前須知事項

使用本产品前，请先仔细阅读本说明书以及硬件所对应的说明书，阅读后请妥善保管，以便将来参考之用。

关于安全

- 请将本产品放在儿童拿不到的地方保管。儿童可能会吞下小零件或用连接线缠绕自己，从而造成身体伤害或导致意外发生、机器故障。
- 请勿使用湿手触摸本产品。
- 切勿分解、改造本产品。
- 连接时，请勿让灰尘或异物堆积在端口四周。
- 请勿让液体或小颗粒掉入本产品中。
- 请勿将本产品暴露在灰尘、烟雾或蒸汽中。
- 请勿将本产品放在高温、湿气极重或受日光直射的地方。

使用与保管

- 请勿让金属物品碰触连接端口部位。
- 请勿在本产品上放置重物。请勿站立在本产品上。
- 请勿投掷或掉落本产品，或使其受到强烈的外力撞击。
- 请勿将本产品放在倾斜、不平整或易受震动的地方。
- 请勿让本产品被液体沾湿。
- 请遵循以下使用说明，以避免产品外壳变形或变色。
 - 使用干净软布轻揉擦拭。
 - 切勿在产品外壳上长时间放置任何橡胶或乙烯基材质。
 - 切勿使用溶剂或其他化学药剂。切勿使用经化学处理的布擦拭。

